

## February-19-14 10:41:17 AM

Page 1

1) 14-2-21 DAS  
6  
980

① M.2.21 DAS  
6  
289

**Work Order ID 113501**

February-19-14 10:41:17 AM

**\*113501\***

Page 2

Item ID: D350-567-141

Accept

**\*N900040100\***Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Floor Window Close Out

Start Date: 19/02/2014 Start Qty: 1.00 **\*1\***

Cust Item ID:

Required Date: 28/02/2014 Req'd Qty: 1.00 **\*1\***

Customer:

Reference: REWORK MISSING D4434-041

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_

Run Start **\*NR1\***

QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

125	Identify as per dwg & Stock Location: <u>OS1</u>	0.00							
-----	--	------	--	--	--	--	--	--	--

**\*125\***

Packaging	Memo	0.00							DAS
-----------	------	------	--	--	--	--	--	--	-----

Packaging	RE-PACKAGE USING NEW BATCH NUMBER								6 9-89
-----------	-----------------------------------	--	--	--	--	--	--	--	-----------

135	QC21- Final Inspection - Work Order Release	0.00							
-----	---	------	--	--	--	--	--	--	--

**\*135\***

QC	Memo	0.00							
----	------	------	--	--	--	--	--	--	--

Quality Control

14-2-19

14-02-24

## February-19-14 10:41:30 AM

**Parent Item:** D350-567-141

**\*D350-567-141\***

**Parent Item Name:** Floor Window Close Out

**Start Date:** 19/02/2014

**Required Date:** 28/02/2014

**Start Qty: 1.00**

**Required Qty: 1.00**

**Comments:** IPP REV:A 11.11.09 new issue DD verf:JLM  
12.01.23 AS PER ECN12-511 DD VERF:EC  
AS PER ECN12-537 DD VERF:EC

IPP REV:B  
IPP REV:C 12.03.05

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D350-567-141		Manufactured	No				Each	3.0000		1			
<b>*D350-567-141*</b>									<b>**</b>				
Floor Window Close Out													
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				FG051				3					
				109325				2					
				109824				1					
D4434-041		Manufactured	No				Each	1.0000		1			
<b>*D4434-041*</b>									<b>**</b>				
Fwd Bracket Assembly													
				<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				ST271A				1					
				107529				1					